


HIMALAYAN_ABS_G10_USA_G2_COMPLETE SCHEMATICS_EFI+ABS+AHO+TRIPPER UNIT



FUSE DETAILS:
 F1 - CHARGING FUSE-25A (RR UNIT)
 F2 - MAIN FUSE -25A (ALL SUBSYSTEM FUSES AND LOADS)
 F3 - IGNITION SYSTEM - 15A (EFI SYSTEM)
 F4 - SIGNALLING FUSE -15A (CLUSTER/HORN/TRAFFICATOR/WSS/STOP LAMP)
 F5 - HAZARD FUSE -10A
 F6 - LIGHTING FUSE -15A (HEAD LAMP/POSITION LAMP)
 F7 - ABS MAIN 1 - 15A
 F8 - ABS MAIN 2 - 10A
 F9 - ABS IGNITION - 5A